



# Trailer and Skid Mounted Maintenance Distributors

## Features



Unit shown includes some optional equipment

### STANDARD EQUIPMENT

#### Trailer:

- Trailer consists of adjustable 2 1/2" pintle eye, tandem axles on spring suspension, four LT235/85 R16 (E) tires on disc wheels, crank type jack, electric brakes with breakaway feature and safety chains with hooks, steel fenders, FMVSS-108 lights and wiring, 7 pin electrical connection for towing vehicle and steel parts painted black.

#### Tank:

- Tank construction is a steel shell and full section surge plates, 2" fiberglass insulation covered with aluminum jacketing.
- Manhole: 20" diameter manhole with spill collar and rollover protection.
- Tank thermometer 50° - 400° F. pencil type.
- Measuring stick, Aluminum, 50 gallon increments

#### Power Unit:

- Power unit is a Kubota D902-E3B, 20hp, engine with electric starter, alternator, battery and 20 gallon fuel tank. Includes hydraulic pump, motor and valves for asphalt pump drive.

#### Asphalt Pump:

- Asphalt pump is 200 GPM, hydraulic motor driven.
- Electric analog GPM asphalt pump tachometer.

### TRAILER MOUNTED UNIT:

*Unit requires truck air be available*

#### Circulating System:

- Circulating system includes air powered primary asphalt valves, removable strainer in pump suction line, and a 20 gallon flushing oil tank with line to asphalt pump. System includes all valves for loading, circulating in the tank, hand spraying and unloading, and the suck back system for entire circulating system including spray bar when so equipped.

#### Heating System:

- Heating flue equipped with one Diesel burner, electric driven fuel pump and blower, auto ignition, 500,000 BTUs

#### Spray Bar:

- 8' Full circulating spray bar. Fixed height, non shifting, non folding, air controlled gang on/off with manual flip valve nozzle every 4". Includes spray bar on/off switch in control panel on a 20' electrical cord to reach the chassis cab for trailers, mounted in cab for truck mounts.

#### Hand Spray:

- 25' rubber hand spray hose and three nozzle gun.

## OPTIONAL EQUIPMENT

**Tank:**

- B1. Tank gauge float type with indicator in 50 gallon increments.
- B2. Sample Valve/Gravity Draw off, 3/4".
- B4. Thermometer 2" dial type in addition to standard pencil type.
- B6. Manhole strainer, 20".
- B7. Manhole strainer, 6".

**Heating System:**

- C3. (1) LPG Burner, in lieu of Diesel, includes single rack for 100# bottle (bottle not included).
- C12. 100# LPG bottle.

**Spray Bar:**

- E1. 10' Full circulating spray bar consisting of 8' center section with (2) 1' folding non removable sections with breakaway feature. Height adjustable non shifting with manual wing fold. Air controlled gang on/off with manual flip valve nozzle control every 4". Includes spray bar on/off switch in control panel on a 20' electrical cord to reach the chassis cab for trailer units, mounted in cab for truck mounts.

- E2. 10' full circulating spray bar consisting of 8' center section with (2) 1' folding non removable sections with breakaway feature. Hydraulic power lift and shift with manual wing fold. Air controlled gang on/off with manual flip valve nozzle control every 4". Includes spray bar on/off and lift/shift switches in control panel on a 20' electrical cord to reach the chassis cab for trailer units and mounted in cab for truck mounts.

- E3. Spray bar extensions (each 1') (maximum 16').
- E4. Spray bar delete - no spray bar provided.

**Miscellaneous**

- D4. Radar ground speed indicator with readout in cab control panel.
- H1. Tool box steel (6" x 10" x 30") with hasp for padlock.
- H3. Loading hose, 12' x 3" flexible steel including male fitting each end.
- H6. 3" Cam lock fittings.
- H8. Export processing.
- H10. Ladder to manhole.
- H11. Air compressor, required if truck air is not available.

Capacity	Shell Gauge	Axle Rating	Heating Flue and Burner	Trailer	Skid For Truck Mounting	Truck Mounting at Factory
600	12g	5000#	1	X	X	X
1000	10g	6000#	1	X	X	X



**E. D. ETNYRE & CO.,**

1333 South Daysville Road, Oregon, Illinois 61061  
 Phone: 800-995-2116 or 815/732-2116 • Fax 815-732-7400  
 www.etnyre.com • E Mail: sales@etnyre.com

*E. D. Etnyre & Co., whose policy is one of continuous improvement, reserves the right to change specifications without notice. Some items shown in photos and illustrations may be optional equipment.*